




POMPE A EAU




POMPE A HUILE




EMBRAYAGE

POMPE A ESSENCE




Dynamo 6 Volts




KEY	ITEM	PART NO.	GROUP	KEY	ITEM	PART NO.	GROUP	KEY	ITEM	PART NO.	GROUP
A	PIN	CC-108636	[0601 0601.1]	J	COIL, ASS'Y	CC-916591	[0601 0601.1]	T	BEARING	[CC-962613 CC-636804]	[0601 0601.1]
B	NUT	CC-125250	[0601 0601.1]	K	BRUSH SET	CC-677175	[0601 0601.1]	U	FRAME, ASS'Y	[CC-962612 CC-1089586]	[0601 0601.1]
C	WASHER	CC-120390	[0601 0601.1 0601.2]	L	SPRING	CC-675935	[0601 0601.1 0601.2]	V	ARM	CC-674936	[0601 0601.1]
D	WASHER	CC-674943	[0601 0601.1]	M	WASHER	CC-674930	0601	W	WASHER	CC-120214	[0601 0601.1]
E	WASHER	CC-674928	[0601 0601.1]	N	WASHER	CC-674927	0601.1	X	BOLT	CC-916586	[0601 0601.1]
F	WASHER	CC-674939	[0601 0601.1]	O	COVER	[CC-674932 CC-636800]	[0601 0601.1]	Y	[SCREW WASHER]	[CC-132900 CC-120217]	[0601 0601.1]
G	RETAINER	CC-648395	[0601 0601.1]	P	STRAP	CC-674944	[0601 0601.1]	Z	FRAME, ASS'Y	CC-962614	[0601 0601.1]
H	KEY	CC-103905	[0601 0601.1]	Q	[SCREW WASHER]	[CC-132105 CC-120217]	[0601 0601]	AA	BRACKET	CC-920252	[0601 0601.1]
I	ARMATURE, ASSEMBLY	[CC-962616 CC-1089591]	[0601 0601.1]	R	GASKET	[CC-674931 CC-695627]	[0601 0601.1]	AB	WASHER	CC-120383	[0601 0601.1]
				S	[SCREW WASHER]	[CC-674929 CC-120380]	[0601 0601]	AC	SCREW	CC-122253	[0601 0601.1]

Démarreur 6 Volts




KEY ITEM	PART NO.	GROUP	KEY ITEM	PART NO.	GROUP	KEY ITEM	PART NO.	GROUP
A—STRAP	CC-641457	0603.1 0603.2	L—ARMATURE, ASSEMBLY	CC-641443 CC-648102	0603.1 0603.2	V—SPRING	CC-853752 CC-853754	0603.1 0603.2
B—OILER	CC-643972	0603.1 0603.2	M—LEVER, ASS'Y	CC-919949	0603.1 0603.2	W—COLLAR	CC-853751	0603.1 0603.2
C—FRAME, ASS'Y	CC-641453 CC-636839	0603.1 0603.2	N—DRIVE, ASS'Y	CC-871754 CC-871755	0603.1 0603.2	X—WASHER	CC-669412	0603.1 0603.2
D—BRUSH	CC-636838	0603.1	O—NUT	CC-51104	0603.1 0603.2	Y—BLOCK	CC-636828	0603.1 0603.2
E—SCREW	CC-133629	0603.1 0603.2	P—WASHER	CC-120381	0603.1 0603.2	Z—BOLT WASHER	CC-641454 CC-120214	0603.1 0603.2
F—CONTACT	CC-643838	0603.1 0603.2	Q—SCREW	CC-959467	0603.1 0603.2	AA—SPRING	CC-636841	0603.1 0603.2
G—POST (Serviced in SWITCH, ASS'Y, CC-641462)		0603.1	R—WASHER	CC-120383	0603.1 0603.2	AB—BRUSH	CC-636820	0603.1 0603.2
H—SWITCH, ASS'Y	CC-641462	0603.1	S—BOLT	CC-122267	0603.1 0603.2	AC—HOLDER (Serviced in FRAME, ASS'Y, CC-641453)		0603.1
I—SCREW WASHER	CC-121540 CC-138479	0603.1	T—HOUSING	CC-919950 CC-959451	0603.1 0603.2	AD—NUT	CC-120611	0603.1 0603.2
J—POST	CC-636822 CC-648342	0603.1 0603.2	U—WASHER	CC-641444	0603.1 0603.2	AE—SCREW	CC-132930	0603.1 0603.2
K—WASHER	CC-641445	0603.1 0603.2						


Allumeur




BOITE DE VITESSES




BOITE AUXILIAIRE (type 4x4)




BOITE DE TRANSFERT (type 6x6)




Pillow-Block



CE DIFFERENTIEL EST MONTÉ SUR LES CHASSIS JUSQU'AU
N° 81657582 ET DE 81674101 A 81674747.




DIFFERENTIEL 1^{er} (type)






CE DIFFERENTIEL EST MONTE SUR LES CHASSIS DEPUIS LE
N° 81657582 SAUF DE 81674101 A 81674747.


DIFFERENTIEL (type renforcé)







PONT AV




DIRECTION




SYSTEME DE FREINAGE




Amortisseur 1^{er} type




Amortisseur 2^e type




Suspension Avant



Suspension Arrière




RESSORT ARRIÈRE



This technical drawing illustrates a mechanical assembly, likely a pump or valve mechanism, with four circular insets providing detailed views of specific components. The main assembly consists of a vertical shaft (A) passing through a central body (B). At the top, there is a flange (C) and a curved pipe (D). The central body (B) has a series of vertical lines indicating a threaded or ribbed section. Below this, there is a horizontal section (E) and a curved pipe (F). The four circular insets show detailed views of the internal components, including valves, pistons, and connecting rods, labeled with letters G through S. The insets are arranged in a row, each showing a different perspective or detail of the mechanism.

KEY	ITEM	PART NO.	GROUP	KEY ITEM	PART NO.	GROUP	KEY ITEM	PART NO.	GROUP
A	PIPE	{ CC-923483 CC-921962 CC-921958 }	0401	F { BOLT NUT WASHER }	{ CC-916511 CC-120376 CC-138485 }	0401	N { BOLT NUT WASHER }	{ CC-120424 CC-120371 CC-120884 }	0401
B	MUFFLER, ASS'Y	CC-921030	0401	J-BRACKET	CC-921154	0401	O-BRACKET	CC-921967	0401
C	PIPE, ASS'Y	CC-921190	0401	K { BOLT NUT WASHER }	{ CC-121615 CC-120369 CC-120382 }	0401	P-BRACKET	CC-921968	0401
D	MANIFOLD, ASS'Y	CC-1067126	0108	L { BOLT NUT WASHER }	{ CC-121661 CC-120368 CC-120214 }	0401	Q { BOLT NUT WASHER }	{ CC-120647 CC-120369 CC-120382 }	0401
E	GASKET	CC-679023	0401	M-BRACKET	CC-921966	0401			
F	{ BOLT NUT }	{ CC-124133 CC-120370 }	0401						
G	BRACKET	CC-921155	0401						
H	SADDLE	CC-597452	0401						

Treuil Avant



Prise de Force

